

COUNTER


INSTRUCTIONS

INTRODUCTION

The AGRIPLAS FLOW COUNTER has been designed to totalize and measure the flow of any pulsed output water meter. The unit displays the per min and per hour flow speed in litres, as well as a Total of the flow having passed the meter since being started.

INSTALLATION

Securely mount the unit to the wall or cabinet using the 4 casing mountings. Mount this unit at least 2meters away from any high-power lines or pump control boxes.



This unit only uses one dry contact input.

The unit need to be powered from a 9Vdc supply. Only a 9Vdc supply should be used otherwise the unit will be damaged.

PROGRAMMING

